

# Read and Write Control of the HT1380/HT1381

D/N : AN0049E

## Introduction

This application note applies to the HT48xxx and HT46xxx MCU devices. The HT1380/HT1381 is a standard Holtek device which can implement a calendar and clock function in hardware. The only external component required, to ensure correct operation, is a 32K crystal. It is only necessary for the user to write the initial time and date to the device's corresponding register, after which any data read from the HT1380/HT1381 device will provide the current time and date. The device provides excellent accuracy and convenience.

## Driver Description

### Using the Driver

To implement the read and write functions in the HT1380, two drivers are provided. Add the necessary variables in the subroutine to the definition, and add the original file rw\_ht1380.asm to the program. Modifying the I/O definition can be done directly at the .section 'data' by modifying the equ definition.

### Detailed descriptions for each driver

#### Driver Name: READ\_1380

Function: read data from the HT1380  
Entrance argument: none  
Exit argument: acc  
Middle argument: time\_temp, time\_count  
Stack: none


#### Driver Name: WRITE\_1380

Function: read data from the HT1380  
Entrance argument: acc  
Exit argument: none  
Middle argument: time\_temp, time\_count  
Stack: none

```
#include ht48r10a-1.inc
rw_ht1380_data .section      'data'
time_temp      db    ?
time_count     db    ?
ht1380_clk     equ   pa.4
ht1380_clk_ctrl  equ   pac.4
ht1380_io       equ   pa.5
ht1380_io_ctrl  equ   pac.5
ht1380_rest    equ   pa.6
ht1380_rest_ctrl  equ   pac.6

rw_ht1380_code1 .section      'code'
;-----
read_ht1380:
    clr  time_temp
    mov  a,8
    mov  time_count,a
    set  ht1380_io_ctrl
read_ht1380_loop:
    clr  c
    set  ht1380_clk
    sz   ht1380_io
    set  c
    rrc  time_temp
    clr  ht1380_clk
    sdz  time_count
    jmp  read_ht1380_loop
    mov  a,time_temp
    ret
;-----
write_ht1380:
    mov  time_temp,a
    mov  a,8
    mov  time_count,a
    clr  ht1380_io_ctrl
    clr  ht1380_io
write_ht1380_loop:
    rrc  time_temp
    sz   c
    set  ht1380_io
    set  ht1380_clk
    nop
    clr  ht1380_clk
    clr  ht1380_io
    sdz  time_count
    jmp  write_ht1380_loop
    ret
```

## Circuit Hardware



The following example shows how to use the Driver program. The program's function is to first initialize the HT1380, and then obtain the present value from the HT1380 after one minute and forty seconds. The data is saved in BCD code format.

```

;*****
;FILE NAME:      FRONT PANEL
;MCU:           HT48R10A-1
;MAST OPTION:   WDT CLOCK SOURCE: DISABLE WDT
;    CLR WDT: ONE
;    TIMER CLOCK SOURCE: SYSTEM CLOCK
;    WAKE-UP PA: NONE
;    INPUT TYPE PA: SCHMITT TRIGGER
;    PULL-HIGH: PA,PB,PC
;    BZ/BZB: ALL DISABLE
;    LVR: DISABLE
;    OSC: EXT. CRYSTAL
;    FOSC: EXTERNAL
;    SYSVOLT: 5.0V
;    SYSFREQ: 4MHZ
;    PWM: DISABLE
;    PFD: DISABLE
;AUTHOR:        RADOME
;HISTORY:       2003.09.17
;*****
include Ht48r10a-1.inc
    PUSH macro
    mov acc_bk,a
    mov a,status
    mov status_bk,a
    endm

    POP macro
    mov a,status_bk
    mov status,a
    mov a,acc_bk
    endm

;-----
ht1380_clk          equ     pa.4
ht1380_clk_ctrl     equ     pac.4
ht1380_io            equ     pa.5
ht1380_io_ctrl       equ     pac.5
ht1380_rest          equ     pa.6
ht1380_rest_ctrl     equ     pac.6
;*****
FrontPanel_data.section 'data'
;*****
;System

```

```

acc_bk           db      ?
status_bk        db      ?

;ht1380
second          db      ?
minute          db      ?
hour             db      ?
date             db      ?
month            db      ?
day              db      ?
yearh            db      ?
yearl            db      ?
time_count       db      ?
time_temp        db      ?

;BCD/HEX
data_bcd         db      ?
data_hex         db      ?
data_count       db      ?
data_temp        db      ?

f_test           dbit

;*****
FrontPanel_code .section 'code'
;*****



org   0000h
jmp   main

org   0004h           ;External Interrupt
reti

org   0008h           ;Timer Interrupt
timer_int:
push
;macro program for interrupt protection

inc   data_temp
mov   a,data_temp
sub   a,250
snz   c
jmp   timer_end
clr   data_temp

inc   data_count
mov   a,data_count
sub   a,50
snz   c
jmp   timer_end
set   f_test

timer_end:
pop
;macro program for interrupt and return
;the relative register to its original
;status
reti
;*****
;Initializers
;*****


main:
clr   wdt
clr   intc
clr   tmrc

```

```
clr  pa
clr  pac
clr  pb
clr  pbc
clr  pc
clr  pcc           ;initialize the program

mov  a,20h
mov  mp,a
mov  a,64
clr  iar
inc  mp
sdz  acc
jmp  $-3           ;clear the RAM

mov  a,00000101b
mov  intc,a
mov  a,6           ;8ms
mov  tmr,a
mov  a,10000110b
mov  tmrc,a
set  tmrc.4
nop
nop
nop
clr  tmrc.4
mov  a,6           ;8ms
mov  tmr,a
mov  a,10010110b
mov  tmrc,a

mov  a,00h
mov  second,a
mov  a,59h
mov  minute,a
mov  a,23h
mov  hour,a
mov  a,30h
mov  date,a
mov  a,09h
mov  month,a
mov  a,02h
mov  day,a
mov  a,03h
mov  yearl,a
call  init_ht1380 ;write in 03-09-30 23:59:00

snz  f_test
jmp  $-1
call  get_time
jmp  $           ;read the value after 1 min and 40
;seconds

*****;
;ht1380
*****;
-----;
;Initialize ht1380
-----;
init_ht1380:
```

```
    clr    ht1380_rest_ctrl
    clr    ht1380_clk_ctrl
    clr    ht1380_io_ctrl

    clr    ht1380_rest
    nop
    set    ht1380_rest
    mov    a,10001110b
    call   write_ht1380
    mov    a,00000000b
    call   write_ht1380      ; disable te write protect
    clr    ht1380_rest
    nop
    set    ht1380_rest
    mov    a,10111110b      ; burst mode command
    call   write_ht1380
    mov    a,second          ; "CH" bit set 0
    call   write_ht1380
    mov    a,minute
    call   write_ht1380
    mov    a,hour
    call   write_ht1380
    mov    a,date
    call   write_ht1380
    mov    a,month
    call   write_ht1380
    mov    a,day
    call   write_ht1380
    mov    a,yearl
    call   write_ht1380
    clr    ht1380_rest
    ret
;-----
;Write ht1380
;-----
write_ht1380:
    mov    time_temp,a
    mov    a,8
    mov    time_count,a
    clr    ht1380_io_ctrl
    clr    ht1380_io
    write_ht1380_loop:
    rrc    time_temp
    sz    c
    set    ht1380_io
    set    ht1380_clk
    nop
    clr    ht1380_clk
    clr    ht1380_io
    sdz    time_count
    jmp    write_ht1380_loop
    ret
;-----
;Get time
;-----
get_time:
    clr    ht1380_rest_ctrl
    clr    ht1380_clk_ctrl
    clr    ht1380_io_ctrl

    clr    ht1380_rest
```

```
    nop
    set    ht1380_rest
    mov    a,1011111b          ;burst mode command
    call   write_ht1380
    nop
    call   read_ht1380
    mov    second,a
    call   read_ht1380
    mov    minute,a
    call   read_ht1380
    mov    hour,a
    call   read_ht1380
    mov    date,a
    call   read_ht1380
    mov    month,a
    call   read_ht1380
    mov    day,a
    call   read_ht1380
    mov    yearl,a
    clr    ht1380_rest
    ret
;-----
;Read ht1380
;-----
read_ht1380:
    clr    time_temp
    mov    a,8
    mov    time_count,a
    set    ht1380_io_ctrl
read_ht1380_loop:
    clr    c
    set    ht1380_clk
    sz    ht1380_io
    set    c
    rrc    time_temp
    clr    ht1380_clk
    sdz    time_count
    jmp    read_ht1380_loop
    mov    a,time_temp
    ret
*****BCD&HEX*****
;BCD to HEX
;-----
bcd2hex:
    swapa data_bcd
    and    a,0fh
    rl    acc
    mov    data_temp,a
    rl    acc
    rl    acc
    addm  a,data_temp
    mov    a,data_bcd
    and    a,0fh
    add    a,data_temp
    mov    data_hex,a
    ret
;-----
;HEX to BCD
```

```
;-----  
hex2bcd:  
    clr    data_bcd  
    mov    a,8  
    mov    data_count,a  
hex2bcd_loop:  
    rlc    data_hex  
    mov    a,data_bcd  
    adc    a,data_bcd  
    daa    data_bcd  
    sdz    data_count  
    jmp    hex2bcd_loop  
    ret  
;*****  
end
```

## Revision History

Revision: V1.10

Updated Date: January 2, 2012

Modified Contents: Modify heading from HT1380 to HT1380/HT1381 to reflect addition of new part number.